


USE OF THE 1005-223-03 & 03A BOLT ROLLER GREASER
for use with the M14/M1A Rifles



1. Insure magazine is removed and chamber is clear, remove bolt per instruction manual.
2. Fill cup with Rifle grease approx. 3/4 full.
3. Press cup over Bolt Roller, allow grease to flow out of the back of the roller
4. Remove greaser and clean up over flow

This product is sold "as is" and without any warranty. No liability is expressed or implied for damage or injury which may result from the improper installation or use of this product.