

## Use of the 306-88 SNAP (Scope, Nightvision Adapter, Pocket) Mk 4

For use with the M151 (Leupold Mk 4 12-40X60mm) Spotting scope and AN/PVS-14 Night vision Monocular.

NOTE: The SNAP is Laser Interference Filter (LIF) compatible

Remove and store the rubber eyecup from the eyepiece by gently pulling out and back (fig. A).

Slip the Locking ring (As shown) of the SNAP on to the spotter eyepiece till it comes to a stop.  
Tighten the locking ring snugly, do not rotate the body!

### CAUTION!

**Do not tighten the locking ring when the device is not mounted on the spotting scope.**

This may result in damage to the collet fingers and render the unit inoperable.

Slip the Objective lens of the PVS-14 into the back of the SNAP until it stops.

Adjust Spotter and PVS-14 focus until desired power and focus is achieved.

To remove reverse above procedure.

